

NBOLLARD 220-240V AC 50/60HZ



The Bollard series was designed using modern simulation methods in order to obtain the highest product quality.


based on CREE LEDs

- IP65
- made of aluminum
- 220-240V DC
- 5-year warranty
- 24 W




Working temperature range	-20°C ÷ +55°C
IP protection class	IP65
Lifetime L80B10	≥ 65 000h
Impact resistance	IK10
Protection class	I
Connection	0.5m
Dimming	ON-OFF/DALI-2 DT6
Luminous flux tolerance	±10%
Angle of distribution	360°

TECHNICAL DRAWINGS



NBOLLARD 220-240V AC 50/60HZ




The Niviss outdoor LED lighting fixture can be used for lighting many places and objects such as:

- parks
- gardens
- exterior walls
- squares
- premises
- plants

ELECTRICAL INSTALLATION

Connecting to the power supply should be done when the power supply is off.



ORDER CODE AND TECHNICAL SPECIFICATIONS OF VARIANTS

VARIANT CODES IN THE TABLE BELOW TECHNICAL SPECIFICATIONS OF VARIANTS IN DATASHEET OF VARIANT

GENERAL TERMS OF USE

- Before using a luminaire, make sure what voltage range it is designed to.
- Connecting to the power supply should be done when the power supply is off.
- Use appropriate sockets and plugs: Ensure that your electrical sockets and plugs are compatible with the lamp's voltage and plug type.
- Use appropriate wiring for luminaires.
- Avoid overloading electrical circuits by not connecting too many lamps to a single outlet or circuit. Check the condition of the power cord and plug for any signs of damage or wear.
- Pay attention to the correct polarity when connecting the luminaires. Incorrect polarity may prevent the luminaires from functioning properly or could potentially damage them.
- Installation of the luminaires should be done by qualified person.
- Keep your luminaires clean and free from dust and debris, as it can affect their performance.
- Follow the luminaire connection diagram above.
- Avoid direct exposure of bright light sources to your eyes. Position luminaires in a way that minimizes direct glare or uncomfortable brightness.
- Ensure that the luminaire is placed on a stable surface and kept away from flammable materials. Allow sufficient clearance around the luminaire to prevent overheating.
- Keep away from fire.
- Make sure your electrical installations are properly grounded and meet the necessary safety standards. Avoid overloading circuits by not connecting too many lamps to a single outlet or circuit.
- Pay attention on correct connection of Line and Neutral to electric network.

ENVIRONMENTAL CAUTION!

It is prohibited to dispose of obsolete and waste electrical and electronic equipment together with regular household wastes. They should be properly sorted and recycled. Old electrical and electronic equipment should be returned to a waste collection point established by a waste-management service. Waste electrical and electronic equipment can be broken down to base materials and then recycled. For more information regarding waste management please contact your local authorities, waste-management service or the seller of electrical and electronic devices.

ORDER CODE AND TECHNICAL SPECIFICATIONS OF VARIANTS

Index	[DEG]	[K]	Lumen Output [lm]	CRI/RA	[W]	Power supply type	Body material	Front material	EAN
NBOLLARD-24-WW-250-BK-ON-HV	360	3000	1100	≥80	24	HV	Alu	Alu	5905658703295
NBOLLARD-24-WW-600-BK-ON-HV	360	3000	1100	≥80	24	HV	Alu	Alu	5905658703301
NBOLLARD-24-WW-1000-BK-ON-HV	360	3000	1100	≥80	24	HV	Alu	Alu	5905658703318
NBOLLARD-24-NW-250-SR-ON-HV	360	4000	1150	≥80	24	HV	Alu	Alu	5905658703325
NBOLLARD-24-WW-600-BK-DALI-HV	360	3000	1100	≥80	24	HV	Alu	Alu	5905658703424
NBOLLARD-24-NW-1000-BK-DALI-HV	360	4000	1150	≥80	24	HV	Alu	Alu	5905658703493
NBOLLARD-24-NW-600-BK-DALI-HV	360	4000	1150	≥80	24	HV	Alu	Alu	5905658703486
NBOLLARD-24-NW-600-SR-DALI-HV	360	4000	1150	≥80	24	HV	Alu	Alu	5905658703455
NBOLLARD-24-WW-600-SR-DALI-HV	360	3000	1100	≥80	24	HV	Alu	Alu	5905658703394
NBOLLARD-24-WW-250-BK-DALI-HV	360	3000	1100	≥80	24	HV	Alu	Alu	5905658703417
NBOLLARD-24-WW-1000-SR-DALI-HV	360	3000	1100	≥80	24	HV	Alu	Alu	5905658703400
NBOLLARD-24-NW-250-BK-DALI-HV	360	4000	1150	≥80	24	HV	Alu	Alu	5905658703479
NBOLLARD-24-NW-1000-SR-DALI-HV	360	4000	1150	≥80	24	HV	Alu	Alu	5905658703462
NBOLLARD-24-NW-250-SR-DALI-HV	360	4000	1150	≥80	24	HV	Alu	Alu	5905658703448
NBOLLARD-24-WW-1000-BK-DALI-HV	360	3000	1100	≥80	24	HV	Alu	Alu	5905658703431
NBOLLARD-24-WW-250-SR-DALI-HV	360	3000	1100	≥80	24	HV	Alu	Alu	5905658703387
NBOLLARD-24-NW-600-SR-ON-HV	360	4000	1150	≥80	24	HV	Alu	Alu	5905658703332
NBOLLARD-24-NW-1000-SR-ON-HV	360	4000	1150	≥80	24	HV	Alu	Alu	5905658703349
NBOLLARD-24-NW-1000-BK-ON-HV	360	4000	1150	≥80	24	HV	Alu	Alu	5905658703370
NBOLLARD-24-NW-600-BK-ON-HV	360	4000	1150	≥80	24	HV	Alu	Alu	5905658703363
NBOLLARD-24-NW-250-BK-ON-HV	360	4000	1150	≥80	24	HV	Alu	Alu	5905658703356
NBOLLARD-24-WW-250-SR-ON-HV	360	3000	1100	≥80	24	HV	Alu	Alu	5905658703264
NBOLLARD-24-WW-600-SR-ON-HV	360	3000	1100	≥80	24	HV	Alu	Alu	5905658703271
NBOLLARD-24-WW-1000-SR-ON-HV	360	3000	1100	≥80	24	HV	Alu	Alu	5905658703288